



FIREYE Inc.  
3 Manchester Road  
Derry, NH 03038 USA  
Tel: (603) 432-4100

## Instruction Sheet 133-711

### Installation of IR Filter and O-Ring Retainer for use with Insight 95IRS2-2 Flame Scanners

The IR filter is used to prevent detection cell saturation by reduction of the amount of light entering the cell of the IR scanner.

Hold the scanner with the display downwards so the IR cell can be seen by looking from above through the front section as shown. Place the filter through the front of the lens holder and position it over the IR Cell as shown. Place the securing O-Ring over the filter as shown to retain it in position.

