



Typical wiring for the SB Series Remote Display, Model SB510

This diagram is provided for general reference only, and can also be extended to the SB Series No-Purge and Modulation models. Local codes and your application will determine the actual wiring requirements. Refer to Instruction Manual SB-2501 for details on the SB Series and the messages displayed. If the keypad-reset function is not required, bypass the connections to R1 and R2 of the display so that terminal 1 of the SB Series control is supplied by the power switch.

